## **QUICK-START GUIDE**


## As used with Thinklogical's Velocitykvm-24DH **Dual Data Port/HID Fiber Extension System**


Complete steps 1 through 8 to connect your Thinklogical VX80 Router KVM Matrix Switch

EMAIL:


support@thinklogical.com

router **KVM Matrix Switch** Powered by **MRTS** Technology





## The VX80 Router Critical Hardware Alarms: (Located at the top, left rear of the unit.)



GROUND

POWER SUPPLY 1 (LEFT): Fan failure, temperature spikes, DC voltage and/or current out of range, AC power input interruption and module removed POWER SUPPLY 2 (RIGHT): Fan failure, temperature spikes, DC voltage and/or current out of range, AC power input interruption and module removed FANS: Individual fan monitoring **TEMPERATURE WARNING:** Chassis over temperature, multiple sensors TEMPERATURE SHUTDOWN: Chassis over temperature causing shutdown

**CPU:** Card failure (Only with a redundant card) INPUT/OUTPUT CARDS: SFP+ failure, laser output fault ANY OF THE ABOVE COMMON

Visit us online at www.thinklogical.com for more product information, current updates and the complete line of Thinklogical® products.